

Rural Pathways

Typical base build up for pedestrian use

0.5mm dia grit cast onto uncured surface

Surface Course

Hand applied and trowelled to a smooth finish by Chameleon Ways certified applicators

Binder/Sealing Course

Laid by others in well compacted layers to a minimum fall of 1.5%

Sub-base

Laid by others in well compacted layers to a minimum fall of 1.5%

Sub-grade



Addabound resin bound paving depth requirements

3mm mix requires a minimum depth of 1/2 inch
6mm mix requires a minimum depth of 5/8 inch
10mm mix requires a minimum depth of 7/8 inch

2 inch depth of 12.5mm binder/sealing course installed in compliance with current DOT specifications

4 inch depth of well compacted non-frost susceptible sub base material installed in compliance with DOT specifications

(optional) geotextile membrane to prevent upward migration of fine soil particles

Newly laid bituminous surfaces are able to be treated 30 days or longer after installation to be sure all volatiles have dissipated from the surface. Newly placed concrete surfaces are able to be treated upon complete cure of concrete approximately 30-90 days after placement. If areas need to be installed sooner please consult with your approved Addabound installer.



NOTE: A suitable steel, wood, brick, stone or aluminium edging should be provided to ensure a neat edge detail.

Any advice, recommendation or information given by Chameleon Ways, Inc is based on practical experience and is believed to be accurate at the time of publication, no liability or responsibility of any kind (including liability for negligence) is accepted in this respect by the company, its employees, or applicators.

It is recommended that a certified professional engineer design and develop the proper base structure requirements to support the expected loads and taking into account the climate and site specific conditions which may exist.